

## Guida configurazione sicurezza senza fili

- 1) Per impostare la sicurezza senza fili si deve connettere alla sua rete via cavo. Entrare nella pagina di configurazione del F5D7132 e cliccare sulla voce 'Security'

**BELKIN. Wireless Setup Utility**

**Wireless**

- Basic
- Security**
- Specify IP Address
- MAC Address Control
- Wireless Clients

**Utilities**

- Restart AP
- Restore Factory Default
- Save/Backup Settings
- Restore Previous Settings
- Firmware Update
- System Settings

**Status**

Version Info		LAN Settings	
Firmware Version	F5D7132v1_UK_5.01.11	LAN/WLAN MAC	00:11:50:B9:17:24
Boot Version	51.0.2.0	IP address	192.168.2.254
Hardware	054054000010	Subnet mask	255.255.255.0

Features	
SSID	belkin54g
Security	WPA-PSK
Repeater	Disabled

- 2) Cliccare su 'Submit' senza inserire nessuna password

**BELKIN. Wireless Setup Utility**

**Wireless**

- Basic
- Security
- Specify IP Address
- MAC Address Control
- Wireless Clients

**Utilities**

- Restart AP
- Restore Factory Default
- Save/Backup Settings
- Restore Previous Settings
- Firmware Update
- System Settings

**Login**

Before you can change any settings, you need to log in with a password. If you have not yet set a custom password, then leave this field blank and click "Submit."

**Password**

Default = leave blank

- 3) Dal menu a tendina selezionare 'WPA-Personal (PSK)'

**BELKIN. Wireless Setup Utility**

**Wireless > Security**

**Security Mode**

- Disabled
- WPA-Personal (PSK)**
- 128bit WEP
- 64bit WEP
- WPA2-Personal (AES)

You can configure wireless security. Security should be enabled to assure maximum security. WPA (Wired Equivalent Privacy) provides dynamic key change wireless environments, where WEP (Wired Equivalent Privacy) should be used. More information is available in the user manual.

- 4) Nel campo 'Pre-shared Key (PSK)' cambiare la password predefinita con una propria (minimo 8 caratteri) e cliccare su 'Apply Changes'

**BELKIN. Wireless Setup Utility**

**Wireless > Security**

Security Mode > WPA-Personal (PSK) ▼

Encryption Technique > TKIP ▼ Default is TKIP

Pre-shared Key (PSK) > 12345678

Obscure PSK >

**WPA-PSK (no server)**  
 Wireless Protected Access with a Pre-Shared Key: The key is a password, in the form of a word, phrase or series of letters and numbers. The key must be between **8** and **63** characters long and can include spaces and symbols. Each client that connects to the network must use the same key (Pre-Shared Key) [More Info](#)

Clear Changes Apply Changes

- 5) Una volta salvato le modifiche , restera sempre nella stessa pagina, cliccare su 'Logout' (in alto a destra)

Wireless Setup Utility Home Help Logout

**Wireless > Security**

Security Mode > WPA-Personal (PSK) ▼

Encryption Technique > TKIP ▼ Default is TKIP

Pre-shared Key (PSK) > lbst1234

Obscure PSK >

**WPA-PSK (no server)**  
 Wireless Protected Access with a Pre-Shared Key: The key is a password, in the form of a word, phrase or series of letters and numbers. The key must be between **8** and **63** characters long and can include spaces and symbols. Each client that connects to the network must use the same key (Pre-Shared Key) [More Info](#)

Clear Changes Apply Changes

- 6) Nella pagina 'Status' può controllare se la sicurezza é stata abilitata.

Status

Version Info		LAN Settings	
Firmware Version	F5D7132v1_UK_5.01.11	LAN/WLAN MAC	00:11:50:B9:17:24
Boot Version	51.0.2.0	IP address	192.168.2.254
Hardware	054054000010	Subnet mask	255.255.255.0

  

Features	
SSID	belkin54g
Security	WPA-PSK
Repeater	Disabled

- 7) Adesso l' Access Point é pronto per essere utilizzato. Quando cercherà di connettersi senza fili gli sarà richiesta la chiave di rete (password impostata nel passaggio 4).