

Installation Instructions for the USB Video Adapter
(F5U206 / F5U207)
for Windows® 2000 Professional Edition.

HARDWARE INSTALLATION

There are two video plugs attached to the adapter which you can connect to your camera or VCR...

1. S Video - Black 4 pin female plug
2. RCA Video - yellow female plug

Determining which cable you use relies on the output options on your camera or VCR.

- The S Video option captures both audio and video into your PC. -
 - The RCA Video option **only captures video.** - To Capture audio you will need two additional red and white RCA cables that attach from the output ports of your camera or VCR to the "line-in" port on your sound card. Included in your Usb Video Adapter packaging is an RCA to Stereo splitter cable. This adapter converts two RCA audio plugs (left & right speaker) to a single stereo plug thus making it possible for audio recording.
1. Plug the power cord of your camera or VCR into a nearby electrical outlet.
 2. Turn your camera, VCR, or other media device "on" and set it to 'preview' or 'standby' mode. **Make sure you follow this step as written...Plugging in USB devices not turned on will prevent the camera from being detected.**
 3. Attach the S Video or RCA cable(s) to your device. **Do not plug in the USB end of the cable to your PC until you are prompted to during the Software Installation steps below.**
 4. Plug the RCA audio cables into the RCA to Stereo cable (provided)
 5. Plug in the stereo jack into the "line-in" port on your sound card.

SOFTWARE INSTALLATION

Download the most recent drivers - go to www.belkin.com

1. Put a blank 3 1/2" floppy diskette into drive
2. Execute the downloaded file by double-clicking it. A 'Self Extraction Wizard' will appear. Please follow the on-screen instructions. The extraction tool will place all files onto the 3 1/2" floppy disk you inserted into the 'A:' drive. The 3 1/2" diskette you inserted is now your new installation disk. Use this disk for the following installation procedures....

Since USB is "hot swappable" it is best to have your PC turned on and in a Windows session before you continue.

3. Attach the USB Video Adapter to an available USB port on your PC.

The "Found New Hardware" wizard appears.

4. Click "NEXT"...

The "Install Hardware Device Drivers" window will appear.

5. Select "Search for a suitable device (recommended)."

6. Click "Next>"...

The "Locate Driver Files" window will appear...

7. Select "Floppy disk drives."

8. Click "Next>"...

The "Driver Files Search Results" window will appear...

9. Click "Next>"...

The "Hardware Install" window will appear and will begin copying files...

The "Completing the Found New Hardware Wizard" window will appear..

10. Click "Finish."

The USB Video Adapter is now installed...

11. Install the accompanying video editing software included with your unit.

TESTING YOUR VIDEO ADAPTER

1. Check to see if the Video Adapter is configured and working...

2.

a. Place the installation disk into the "A:\\" drive.

b. Click "Start..."

c. Select "Run" from the 'start menu'.

d. Type in the "Open" field 'A:\amcap.exe'

The "amcap.exe" program is a test for sampling live video from your media device. It may be necessary to adjust the settings in this program to get video...Please consult the help files for further information.

Further support can be found via our web site at www.belkin.com or you can call Belkin Technical support at (800) 223 - 5546 x2263