

No.	Brand Name	MFP Model	Windows 2000 & XP			
			Print	Scan	Fax	Card Reader
1.	HP	CM1015MFP	✓	✓	N/A	N/A
2.	HP	Desk Jet F380	✓	✓	N/A	N/A
3.	HP	Laser Jet 1020 (GDI)	✓	N/A	N/A	N/A
4.	HP	Laser Jet 1022 (GDI)	✓	N/A	N/A	N/A
5.	HP	Laser Jet 3015	✓	✓	✓	N/A
6.	HP	Laser Jet 3020	✓	✓	✓	N/A
7.	HP	Laser Jet 3030	✓	✓	✓	N/A
8.	HP	Laser Jet 3050	✓	✓	--	N/A
9.	HP	Laser Jet 3052	✓	✓	N/A	N/A
10.	HP	Laser Jet 3055	✓	✓	--	N/A
11.	HP	Laser Jet 3380	✓	✓	✓	N/A
12.	HP	Laser Jet 3390	✓	✓	--	N/A
13.	HP	Laser Jet 3392	✓	✓	--	N/A
14.	HP	Laser Jet M1005MFP	✓	--	N/A	N/A
15.	HP	PSC 750	✓	✓	N/A	N/A
16.	HP	PSC 1210	✓	✓	N/A	N/A
17.	HP	PSC 1350	✓	✓	N/A	N/A
18.	HP	PSC 1410	✓	✓	N/A	N/A
19.	HP	PSC 1510	✓	✓	N/A	N/A
20.	HP	PSC 1610	✓	✓	N/A	✓
21.	HP	PSC 2210	✓	✓	--	✓
22.	HP	PSC 2310	✓	✓	N/A	✓
23.	HP	PSC 2355	✓	✓	N/A	✓
24.	HP	PSC 2410	✓	✓	N/A	✓
25.	HP	PSC 2510	✓	✓	N/A	✓
26.	HP	Photosmart 2575	✓	✓	N/A	✓
27.	HP	Photosmart 2610	✓	✓	--	✓
28.	HP	Photosmart 2710	✓	✓	--	✓
29.	HP	Photosmart 3110	✓	✓	✓	✓
30.	HP	Photosmart 3310	✓	✓	--	✓
31.	HP	Photosmart 475	✓	N/A	N/A	✓
32.	HP	Photosmart 7450	✓	N/A	N/A	✓
33.	HP	Photosmart 7830	✓	N/A	N/A	✓
34.	HP	Photosmart 8030	✓	N/A	N/A	✓
35.	HP	Photosmart 8230	✓	N/A	N/A	✓

'N/A' means that the MFP doesn't support the function.

'--' means that the function is not being tested yet.

No.	Brand Name	MFP Model	Windows 2000 & XP			
			Print	Scan	Fax	Card Reader
36.	HP	Photosmart 8250	✓	N/A	N/A	✓
37.	HP	Photosmart 8450	✓	N/A	N/A	✓
38.	HP	Photosmart 8750	✓	N/A	N/A	--
39.	HP	Photosmart C3180	✓	✓	N/A	--
40.	HP	Photosmart D5160	✓	N/A	N/A	--
41.	HP	Photosmart D7160	✓	N/A	N/A	--
42.	HP	Photosmart D7360	✓	N/A	N/A	--
43.	HP	Office Jet 4255	✓	✓	--	N/A
44.	HP	Office Jet 4355	✓	--	--	N/A
45.	HP	Office Jet 5510	✓	✓	--	N/A
46.	HP	Office Jet 5610	✓	✓	--	N/A
47.	HP	Office Jet 6110	✓	✓	--	N/A
48.	HP	Office Jet 6210	✓	✓	--	N/A
49.	HP	Office Jet 6310	✓	--	--	N/A
50.	HP	Office Jet 7130	✓	--	--	--
51.	HP	Office Jet 7210	✓	✓	--	✓
52.	HP	Office Jet 7410	✓	✓	--	✓
53.	HP	Office Jet 9100	✓	✓	--	✓
54.	HP	Office Jet 9100	✓	✓	--	✓
55.	EPSON	CX1500	✓	✓	N/A	N/A
56.	EPSON	CX3700	✓	✓	N/A	N/A
57.	EPSON	CX4100	✓	✓	N/A	N/A
58.	EPSON	CX4700	✓	✓	N/A	✓
59.	EPSON	EPL-6200L (GDI)	✓	N/A	N/A	N/A
60.	EPSON	PHOTO 4990 Scanner	N/A	✓	N/A	N/A
61.	EPSON	R310	✓	N/A	N/A	--
62.	EPSON	R340	✓	N/A	N/A	✓
63.	EPSON	R350	✓	N/A	N/A	✓
64.	EPSON	RX430	✓	✓	N/A	✓
65.	EPSON	RX510	✓	✓	N/A	✓
66.	EPSON	RX520	✓	✓	N/A	✓
67.	EPSON	RX530	✓	✓	N/A	✓
68.	EPSON	RX630	✓	✓	N/A	✓
69.	EPSON	RX650	✓	✓	N/A	✓
70.	CANON	FAXPHONE L120	✓	N/A	--	N/A

\*N/A' means that the MFP doesn't support the function.

'--' means that the function is not being tested yet.

No.	Brand Name	MFP Model	Windows 2000 & XP			
			Print	Scan	Fax	Card Reader
71.	CANON	MPC 190	✓	✓	N/A	N/A
72.	CANON	PIXMA MP110	✓	✓	✓	N/A
73.	CANON	PIXMA MP130	✓	✓	✓	N/A
74.	CANON	PIXMA MP150	✓	✓	N/A	N/A
75.	CANON	PIXMA MP160	✓	✓	N/A	N/A
76.	CANON	PIXMA MP170	✓	✓	N/A	✓
77.	CANON	PIXMA MP180	✓	✓	N/A	--
78.	CANON	PIXMA MP450	✓	✓	N/A	✓
79.	CANON	PIXMA MP510	✓	✓	N/A	--
80.	CANON	PIXMA MP530	✓	✓	--	N/A
81.	CANON	PIXMA MP700	✓	✓	--	✓
82.	CANON	PIXMA MP730	✓	✓	--	✓
83.	CANON	PIXMA MP780	✓	✓	--	✓
84.	CANON	PIXMA MP810	✓	✓	N/A	--
85.	LEXMARK	P4350	✓	✓	N/A	✓
86.	LEXMARK	P6210	✓	✓	N/A	✓
87.	LEXMARK	P6250	✓	--	N/A	--
88.	LEXMARK	X2350	✓	--	N/A	N/A
89.	LEXMARK	X3330	✓	✓	N/A	N/A
90.	LEXMARK	X3350	✓	✓	N/A	N/A
91.	LEXMARK	X3470	✓	--	N/A	--
92.	LEXMARK	X4270	✓	✓	--	N/A
93.	LEXMARK	X5150	✓	✓	N/A	N/A
94.	LEXMARK	X6150	✓	✓	✓	N/A
95.	LEXMARK	X6170	✓	✓	✓	N/A
96.	LEXMARK	X7170	✓	✓	--	N/A
97.	LEXMARK	X7350	✓	--	--	N/A
98.	LEXMARK	Z617 (GDI)	✓	N/A	N/A	N/A
99.	LEXMARK	Z735 (GDI)	✓	N/A	N/A	N/A
100.	Brother	MFC-210C	✓	✓	✓	✓
101.	Brother	MFC-215C	✓	✓	✓	✓
102.	Brother	MFC-2820	✓	N/A	✓	N/A
103.	Brother	MFC-420CN	✓	✓	✓	✓
104.	Brother	MFC-425CN	✓	✓	✓	✓
105.	Brother	MFC-3240C	✓	✓	✓	N/A

\*N/A' means that the MFP doesn't support the function.

'--' means that the function is not being tested yet.

No.	Brand Name	MFP Model	Windows 2000 & XP			
			Print	Scan	Fax	Card Reader
106.	Brother	MFC-7420	✓	✓	✓	N/A
107.	Brother	MFC-7820N	✓	✓	✓	N/A
108.	Brother	MFC-8840D	✓	✓	✓	N/A
109.	Konica Minolta	1380MF	✓	✓	N/A	N/A
110.	Konica Minolta	2480	✓	✓	N/A	N/A
111.	Samsung	SF-565P	✓	✓	✓	N/A
112.	Samsung	SCX-4100	✓	✓	N/A	N/A
113.	Samsung	SCX-4720F	✓	✓	✓	N/A
114.	Dell	944	✓	✓	N/A	✓
115.	BenQ	CM3000	✓	✓	N/A	N/A

'N/A' means that the MFP doesn't support the function.

'--' means that the function is not being tested yet.